

TABLE 1004(g)2-MINIMUM LENGTH OF POSITIVE REINFORCEMENT

Strip	Percentage of required reinforcing steel area to be extended at least as indicated	Maximum distance from centerline of column and of straight bar or bend point of bent bar to end of strip without drop panel			
		Straight	Bend point where bars bend up and continue as negative reinforcement	Straight	Bend point where bars bend up and continue as negative reinforcement
Column strip reinforcement	Not less than 33 percent	0.125L		Minimum end bedment in drop panel of 16 bar diameter but at least 10 in.	
	Not less than 50 percent*	3 in. or 0.25L		Minimum end bedment in drop panel of 16 bar diameter but at least 10 in.	
	Remainder*	0.125L or 0.25L		or	
Middle strip reinforcement	50 percent	0.15L		0.15L	
	50 percent*	3 in. or 0.25L	3 in. or		

*Bars may be straight, bent, or any combination of straight and bent bars. All bars shall be considered straight bars for the end under consideration unless bent at that end and continued as negative reinforcement.

Note: See also Fig. 1004(g).

are omitted shall equal $(t_1 + t_2)/2$ provided the value of c used in the computations complies with Section 1004(c).

(f) Bending moment coefficients

1. The numerical sum of the positive and negative bending moments about the direction of either side of a rectangular panel shall be assumed as not more than

$$M_o = 0.09 WLF \left(1 - \frac{2c}{3L} \right)^2$$

in which $F = 1.15 - c/L$ but not less than 1.

2. Unless otherwise provided, the bending moments at the critical sections of the column and middle strips shall be at least those given in Table 1004(g).

COLUMN STRIP	BENT	STRAIGHT	TYPE BARS	LOCATION	MINIMUM % OF REQUIRED AS AT SECTION		FACE OF SUPPORT	EDGE OF DROP
					TOP	BOTTOM		
COLUMN STRIP	BENT	STRAIGHT	TYPE BARS	LOCATION	50 → Remainder → or 33 → 34 → Remainder → 50 → Remainder →	50 → Remainder → or 33 → 34 → Remainder → 50 → Remainder →	Max. 0.125L Face of support Max. 0.25L Face of support Max. 0.125L Face of support Max. 0.25L Face of support	16 Bar dia. or 10" * Bend outside drop Max. 0.25L 16 Bar dia. or 10" * Edge of drop 16 Bar dia. or 10" * Bend outside drop Max. 0.25L 16 Bar dia. or 10" * Edge of drop
COLUMN STRIP	BENT	STRAIGHT	TYPE BARS	LOCATION	33 → 34 → Remainder → 50 to 67 → 33 to 50 → Total not less than 100	33 → 34 → Remainder → 50 to 67 → 33 to 50 → Total not less than 100	Max. 0.25L Face of support Max. 0.125L Face of support	16 Bar dia. or 10" * Bend outside drop Max. 0.25L 16 Bar dia. or 10" * Edge of drop 16 Bar dia. or 10" * Bend outside drop Max. 0.25L 16 Bar dia. or 10" * Edge of drop

♦ Interior support ♦ Exterior support