

[Previous Screen](#)

## Service Information System

Welcome: h190til

◀ Product: NO EQUIPMENT SELECTED  
Model: NO EQUIPMENT SELECTED  
Configuration: NO EQUIPMENT SELECTED

### Specifications

#### 3500 Marine Engines

Media Number -SENR2373-07

Publication Date -08-01-2013

Date Updated -08-28-2013

i01980486

## Water Pump

SMCS - 1361

**Part Number** - 212-8176

S/N - 96Y1-UP

**Part Number** - 212-8176

S/N - 66Z1-UP

**Part Number** - 212-8176

S/N - 69Z1-UP

## Type 1

---




Illustration 1  
Typical example

g00993011

- (1) Oil seal
- (2) Ring assembly
- (3) Ceramic ring and rubber seal
- (4) Seal assembly
- (5) Spring

Follow these recommendations for installation of the seals:

**Note:** The seal installation tool is part of the replacement seal assembly.

1. Install ring assembly (2) and oil seal (1) into the pump housing. Install the oil seal dry. Do not lubricate the sealing lip. Use the correct installation tool and use a slow, even motion to press the seal into the pump housing.
2. Install shaft (6) through the oil seal.
3. Install the shaft's thrust washer (7).
4. Lubricate the outside diameter of the ceramic ring and rubber seal (3) with clean water.
5. Orient the polished face of the ceramic ring toward seal assembly (4). Use the installation tool and hand pressure to seat the ceramic ring and the rubber seal into the pump housing.
6. Remove spring (5) from the seal assembly. Lubricate the inside diameter of the seal assembly with clean water.

7. Use the seal installation tool and hand pressure to install the seal assembly onto the shaft until the face of the seal assembly makes light contact with the face of the ceramic ring and rubber seal.

8. Install the spring onto the seal assembly.

(6) Shaft

Width of shaft's groove for thrust washer ...  $8.75 \pm 0.05$  mm ( $0.345 \pm 0.002$  inch)

(7) Thrust washer

Thickness ...  $8.50 \pm 0.05$  mm ( $0.3346 \pm 0.0020$  inch)

(8) Nut

Torque ...  $200 \pm 25$  N·m ( $150 \pm 18$  lb ft)

(9) Stud

Torque ...  $35 \pm 5$  N·m ( $26 \pm 4$  lb ft)

(10) Nut

Torque ...  $27 \pm 4$  N·m ( $20 \pm 3$  lb ft)

(11) O-ring seal

Lubricate the O-ring seal with clean engine oil.

(12) O-ring seal

Lubricate the O-ring seal with clean engine coolant.

(13) O-ring seal

Lubricate the O-ring seal with glycerin.

(14) Adapter

Torque ...  $100 \pm 10$  N·m ( $75 \pm 7$  lb ft)

Maximum leakage per minute for the water seal at 138 kPa (20 psi) of air pressure ... 20 cc (1.22 cu in)

Maximum leakage per minute for the oil seal at 138 kPa (20 psi) of air pressure ... 24 cc (1.46 cu in)

## Type 2

---




Illustration 2  
Typical example

g01026565

- (1) Oil seal
- (2) Ring assembly
- (3) Ceramic ring and rubber seal
- (4) Seal assembly
- (5) Spring
- (6) Shaft

Shaft's outer diameter for impeller ...  $25.400 \pm 0.013$  mm ( $1.0000 \pm 0.0005$  inch)  
Width of shaft's groove for thrust washer ...  $8.75 \pm 0.05$  mm ( $0.345 \pm 0.002$  inch)

- (7) Thrust washer

Thickness ...  $8.50 \pm 0.05$  mm ( $0.3346 \pm 0.0020$  inch)

- (8) Impeller

Diameter of impeller's bore ...  $25.342 \pm 0.013$  mm ( $0.9977 \pm 0.0005$  inch)

- (9) O-ring seal
- (10) O-ring seal
- (11) Stud

Torque ...  $35 \pm 5 \text{ N}\cdot\text{m}$  ( $26 \pm 4 \text{ lb ft}$ )

(12) Nut

Torque ...  $27 \pm 4 \text{ N}\cdot\text{m}$  ( $20 \pm 3 \text{ lb ft}$ )

(13) O-ring seal

(14) Adapter

Torque ...  $100 \pm 10 \text{ N}\cdot\text{m}$  ( $75 \pm 7 \text{ lb ft}$ )

## Assembly Procedure

Follow this procedure for assembly:

**Note:** The seal installation tool is part of the replacement seal assembly.

1. Install ring assembly (2) and oil seal (1) into the pump housing. Install the oil seal dry. Do not lubricate the sealing lip. Use the correct installation tool and use a slow, even motion to press the seal into the pump housing.
2. Install shaft (6) through the oil seal and through the ring assembly.
3. Install thrust washer (7).
4. Lubricate the outside diameter of the ceramic ring and rubber seal (3) with clean water or with **207-1600** Rubber Lubricant.
5. Orient the polished face of the ceramic ring toward seal assembly (4). Use the installation tool and hand pressure to seat the ceramic ring and the rubber seal into the pump housing.
6. Remove spring (5) from the seal assembly. Lubricate the inside diameter of the seal assembly with clean water or with **207-1600** Rubber Lubricant.
7. Use the seal installation tool and hand pressure to install the seal assembly onto the shaft until the face of the seal assembly makes light contact with the face of the ceramic ring and rubber seal.
8. Install the spring onto the seal assembly.
9. Lubricate the shaft with clean engine oil. Place the shaft onto a fixture that will absorb the load and press impeller (8) onto the shaft until the face of the impeller is flush with the face of the shaft.
10. Lubricate the bore for O-ring seal (9) with clean engine oil.
11. Lubricate the bore for O-ring seal (10) with clean engine coolant.
12. Tighten studs (11) according to the specified torque.
13. Tighten nuts (12) according to the specified torque.
14. Lubricate the bore for O-ring seal (13) with glycerin.
15. Tighten adapter (14) according to the specified torque.

Maximum leakage per minute for the water seal at 138 kPa (20 psi) of air pressure ... 20 cc (1.22 cu in)

# Maximum leakage per minute for the oil seal at 138 kPa (20 psi) of air pressure ... 24 cc (1.46 cu in)

---

Copyright 1993 - 2017 Caterpillar Inc.  
All Rights Reserved.  
Private Network For SIS Licensees.

Tue Nov 07 2017 17:22:05 GMT-0800 (Pacific Standard Time)  
h190til