

Jacks to be scopped to force ageist load pin and test the weld & structural integrity of padeye.

