



**NON-WORKING BRICK WALL INSTALLATION**  
 DRILL THROUGH EXISTING BRICK WALL  
 REMOVE EXISTING BRICK FROM EACH SIDE OF THE HOLE TO THE FULL DEPTH OF THE HOLE TO BE INSTALLED. THE HOLE SHOULD BE 1/2" DEEPER THAN THE HOLE TO BE INSTALLED.  
 CAREFULLY SAND THE EXISTING WORKING WALL BEHIND THE HOLE TO PREPARE FOR THE NEW BRICKWORK.  
 INSTALL NEW BRICKS IN PLACE, WEEDING TO NEW STEEL ROD TO BEHIND PLASTER END.  
 CAREFULLY REMOVE WORKING FROM THE BRICKS AND MAKE GOOD OF REPAIRS TO BRICKWORK.  
 REMOVE THE DRILL HOLE FROM PROXIMITY OF THE WALL AND PATCH THE WALL AS REQUIRED.