



Dist From NA - $\bar{Y} = 0$

No Shear Flow?

Fasteners Designed To Transfer 100plf To New Ply?