

At high rates, condenser cannot handle

vapor loads. uncondensed vapors from
Condenser will flow through equalization
line in to receiver.

A new vent condenser installed
between receiver and Vacuum pump
should condense excess vapors and drained
back to receiver.

How should y calculate pressure
drop in 2" equalization line?
Is this kind of configuration works
good?

