



1: Force from nut to case. Then from case to inner race of the bearing.

2: Preload from the wave spring to a non rotating case. Then from the case to the outer race.