

INFLUENCE LINES FOR MOMENT
5 CONTINUOUS SPANS - SUPPORTED ENDS
UNIFORM I

W = Uniform load per unit of length
Moment = Coefficient x L
Spans unity - Loads unity























