



- ① DIA 'A' NEEDS TO BE GOOD SURFACE FINISH
- ② KEEP CLEARANCE TIGHT TO PREVENT EXTRUSION
- ③ USE NITRILE ORING. CHEAP TO REPLACE
- ④ YOU CAN USE A $1/8$ SECTION ORING