



39. The hole pattern is for 1/2-inch fasteners. Locate the three holes to each other and perpendicular to the back of the part within the required tolerance. Next specify a profile tolerance perpendicular to the back of the part and located to the hole pattern within .060. Complete the drawing using MMC/MMB wherever possible.