

# Antiquated Structural Systems Series

## Part 4

By D. Matthew Stuart, P.E., S.E., F.ASCE, SECB

This article is the fourth in a series that is intended to provide a resource of information to structural engineers that they can refer to for projects that involve the repair, restoration or adaptive reuse of older buildings for which no drawings exist.

The purpose of this series is to compile and disseminate a resource of information to enable structural engineers to share their knowledge of existing structural systems that may no longer be in use but are capable of being adapted or reanalyzed for safe reuse in the marketplace of today and the future.




Figure 1.

## Prefabricated Clay Tile & Concrete Block Framing Systems

As discussed in the last article in this series, one and two-way joist framing systems were constructed using clay tile and masonry units, which were first arranged and supported on formwork to enable placement of internal reinforcement and infill and topping concrete in situ. In addition, as will be discussed in this article, similar modular clay tile and masonry units were also constructed offsite into prefabricated beams and slabs that could be delivered to the job site. This method of construction ultimately progressed to solid precast concrete

units, which will be addressed in a subsequent article.

The prefabricated clay tile systems included both one-way beam and slab construction and one-way slab construction. The one-way beam system involved the placement of prefabricated beams spaced parallel to each other at regular intervals between already constructed load-bearing walls or steel beams. The areas between the beams were then infilled with tiles that were capable of spanning between each adjacent beam. The one-way slab system involved prefabricated slab units that were placed directly adjacent to each other, spanning between previously constructed load-bearing walls, steel beams or joists. Both the beam and slab systems included a site-cast concrete topping, which was poured over the beams and filler tiles or one-way slabs. The prefabricated beam and slab systems offered the advantage of not having to construct supporting formwork before the framing could be erected; however, shoring in the center of the span was sometimes employed to increase the clear span capability of the members through composite action with the site-cast topping.

Examples of the clay tile systems (Figures 1-6) included the "T" Beam Floor, the "U" Beam System, the Joistile System, the Sheffield Floor System, the Adel Joistile System, the Kalex Floor System, the United Floor System and the Tilecrete Floor System. Some of these systems required filling the joints between the adjacent ends of the clay tile units with mortar, while other systems allowed the ends of adjacent tiles to butt up against each other. All of the prefabricated beam and slab systems, except for the infill tiles, included internal






Figure 2.




Perspective view of standard "Precast Joistile" floor system and typical sectional detail.

Figure 3.




Perspective view of "Sheffield" precast tile floor system and sectional detail.

Figure 4.



Perspective view of "Adel" precast joistile floor system and typical slab section.

Figure 5.



Perspective view of precast "Kalex" tile floor system and typical floor sections.

Figure 6.

longitudinal flexural reinforcement for positive moment resistance. Negative moment reinforcement for continuity across a supporting wall, beam or joist



Flexicore, a product similar to the NABCO Dox Plank, was also available in the 1950s. A hollow core plank is still manufactured today under this same name; however, the current product is a true precast, prestressed concrete member.

In the 1950s, the consulting firm of Bryan and Dozier and the Nashville Brecko Block Company designed and constructed pre-fabricated, post-tensioned concrete block beams. This method of construction resulted in the first linear prestressed structure to be built in the US – the Fayetteville Tennessee High School Stadium – and the first prestressed bridge to be built in the US at Madison County, Tennessee. This method of construction was made practical and economical by the Roebling Company through the development of high-quality tendons that could be bonded without expensive end anchorages.

The Brecko Block system was further refined through the use of external, deflected tendons. However, by the late 1950s, this system was replaced by precast, pretensioned concrete members.

Other, more obscure examples of prefabricated modular concrete block beams and slabs include a prestressed bar system developed by P.H. Jackson of California in 1872; a prestressed wire system developed by C.W. Doering in 1888; a system patented by K.E.W. Jagdmann in 1919; a horizontally draped stressed reinforcement system patented by Albert Stewing and Stefan Polonyi in 1967; and a tensioned, Y-shaped block system patented by Hossein Azimi in 1987.

All of the above tile and concrete block systems were designed based on the basic reinforced masonry and concrete beam analysis theories of their era. Load tables were also commonly developed and published by most of the manufacturers. The problem with all of the above systems, when one encounters them in a building, is that in the absence of existing drawings it is difficult to determine the internal reinforcement and, subsequently, the load carrying capacity of the system. However, it is hoped that this article, by identifying the many different types of products that were in use at one time or another, will assist the readers in their research of an antiquated or archaic system when it is encountered in an existing structure. ■

*D. Matthew Stuart, P.E., S.E., F. ASCE, SECB is licensed in 20 states and has over 30 years experience as a structural consulting engineer. He currently works as a Senior Project Manager at the main office of CMX located in New Jersey and may be contacted at [mstuart@CMXEngineering.com](mailto:mstuart@CMXEngineering.com).*

Future installments of the archaic structural systems series will cover precast concrete framing systems; antiquated post-tensioning systems; structural steel stub-girder; open web steel joist and cast iron construction. If there are other topics along these lines that you would like to see addressed, please send your suggestions and any relevant information that you have to the author.

## References

- “Principals of Tile Engineering,” *Handbook of Design*. Harry C. Plummer and Edwin F. Wanner, Structural Clay Products Institute, 1947. ACI Journal Proceeding, 1918
- “Prestressed Concrete Innovations in Tennessee.” PCI Journal January-February 1979. Ross H. Bryan
- “Dox Plank for High Speed Floor and Roof Construction,” *Design Tables*. NABCO Plank Company. Publication Date – Unknown; Made available by the NCMA – Accession No. TF02657.



**We can  
fix it**

## STRUCTURAL STRENGTHENING SOLUTIONS

FROM AMERICA'S LARGEST SPECIALTY REPAIR CONTRACTOR



### SOLUTIONS FOR:

- Low Concrete Strength
- Honeycomb / Void Repair
- Structural Failure / Damage
- Missing or Misplaced Reinforcement
- New Slab Penetrations
- Increased Loads
- Change in Code
- Seismic Upgrade
- Blast Mitigation

**A situation like this can cause costly delays.** In many cases it can be fixed using proven strengthening techniques and materials that are not common in new construction.

**That's where we come in...** Structural Preservation Systems (SPS) understands the engineering, construction and economic issues facing a scenario like the one above. We know it requires a balance of technical and contracting expertise. We combine our experience in design support and contracting knowledge to work with and support you, the structural engineer.

**Go to our website...** review the case studies and see how you can benefit from our 30+ years of experience helping structural engineers.

**Have an immediate need? Call Lisa Hardy at 800-899-1016.**

Offices Nationwide

[www.spsrepair.com/fix2](http://www.spsrepair.com/fix2) • 800-899-1016