



my IDEALIZATION is TO LIMIT BEARING ONLY AT SLAB BY 100 kPa. IF THIS IS EXCEEDED, I WANT MY EXCESS STRESSES BE CARRIED BY THE WALL FOOTING.

Q: WHAT SPECIAL COMMAND DO I NEED TO APPLY FOR MY SPRING IN ORDER TO MECHANIZE THIS IDEALIZATION?