



## TOGGLED LOAD RESULTS VS. MESH SIZE


### MESH SIZE: 3





### MESH SIZE: 4



### MESH SIZE: 5



### MESH SIZE: 6



Solver suddenly stops and seems to extrapolate linearly? Why?