


WUT CHECKS
NEED TO BE
CARRIED OUT
ON CONNECTION?

SEATED
CONNECTION



SECTION A-A.