



Figure 6.16 Cross-grain bending in a wood member should be avoided.

Because of failures in some ledger connections of this type, cross-grain bending and cross-grain tension are not permitted by the IBC for the anchorage of seismic forces. Even for other loading conditions, designs should generally avoid stressing wood in bending or tension across the grain.