


<30 TRIPS
TRIP DUMP
VALVE RESET

CONTROL OIL PRESS

PG5

L.P. HEADER
60 psig



<150 CLOSURE


SECONDARY
OPERATING
CYLINDER

L.P. STOP VALVE

H.P. STOP VALVE

HYD OIL PRESS

PG1



H.P. HEADER
200 psig

PS21

PS3

PS4B

MOP-2
SUCTION

MAIN OIL
PUMPS

MOP-1
SUCTION

VENT

D.O.C. DUAL OIL
COOLER

D.O.F. DUAL OIL
FILTER

PRV1

PS19C

PRV2

PS28C

PG2

IND. TURBINE BRG. LUBE
OIL PRESSURE

LUBE OIL TO TURB. BRGS
20 psig


INDICATES PUMP BRG
LUBE OIL PRESSURE

PG9

LUBE OIL TO B.F.P. BRGS
20 psig

brg header

20 to 4 in 0.7sec
4 to 12 in 0.7sec



PS6

PS5

EMERGENCY
OIL PUMP

M1