


- 1: Shaft
- 2: Case (avoid movement of the bearing)
- 3: Bearing
- 4: Case (avoid movement of the bearing)
- 5: Nut (Correction plane)
- 6: Non rotating part



Distance between nuts: 230 mm  
Distance between bearings: 140 mm  
Shaft maximum diameter: 47mm