


Flow Curves Inlet and outlet pressures are measured at the valve.
Restrictions in the inlet or outlet piping may reduce the flow.


Air

2C, 4C Series




Water


2C, 4C Series




6C Series



6C Series



8C, 10C, 12C, 16C Series



8C, 10C, 12C, 16C Series

