

Search

Memory Blocks (Group By Id)

- 10-XX: System Configuration
 - 10-01 : Time and Date Setup
 - 10-02 : Location Setup
 - 10-03 : ESI (Channel 1) Configuration
 - 10-03 : SLI Configuration
 - 10-03 : COI Configuration
 - 10-03 : PRI Configuration
 - 10-03 : VOIPDB Configuration
 - 10-03 : PRI (T1) Configuration
 - 10-03 : ESI (Channel 1) Configuration
 - 10-04 : Music On Hold Setup
 - 10-08 : Pre-ringing Setup
 - 10-09 : DTMF and Dial Tone Circuit Setup
 - 10-12 : CPU Network Setup
 - 10-13 : DHCP Server Setup

System Data

10-03 : SLI Configuration

Physical Port	Logical Port	Transmit Gain Level	Receive Gain Level	Select port type
1	9	32	32	SLT ▼
2	10	32	32	SLT ▼
3	11	32	32	SLT ▼
4	12	32	32	SLT ▼
5	0	32	32	SLT ▼
6	0	32	32	SLT ▼
7	0	32	32	SLT ▼
8	0	32	32	SLT ▼

Use Program 10-03: ETU Setup to setup and confirm the Basic Configuration data for each ETU. When ETU.

Search

Memory Blocks (Group By Id)

- 10-XX: System Configuration
 - 10-01 : Time and Date Setup
 - 10-02 : Location Setup
 - 10-03 : ESI (Channel 1) Configuration
 - 10-03 : SLI Configuration
 - 10-03 : COI Configuration
 - 10-03 : PRI Configuration
 - 10-03 : VOIPDB Configuration
 - 10-03 : PRI (T1) Configuration
 - 10-03 : ESI (Channel 1) Configuration
 - 10-04 : Music On Hold Setup
 - 10-08 : Pre-ringing Setup
 - 10-09 : DTMF and Dial Tone Circuit Setup

System Data

10-03 : VOIPDB Configuration

Physical Port	Trunk Logical Port	Trunk Type	Physical Port	Trunk Logical Port	Trunk Type
01	5	SIP ▼	09	0	SIP ▼
02	6	SIP ▼	10	0	SIP ▼
03	7	SIP ▼	11	0	SIP ▼
04	8	SIP ▼	12	0	SIP ▼
05	0	SIP ▼	13	0	SIP ▼
06	0	SIP ▼	14	0	SIP ▼
07	0	SIP ▼	15	0	SIP ▼
08	0	SIP ▼	16	0	SIP ▼

Search

Memory Blocks (Group By Id)

- 10-XX: System Configuration
 - 10-01 : Time and Date Setup
 - 10-02 : Location Setup
 - 10-03 : ESI (Channel 1) Configuration
 - 10-03 : SLI Configuration
 - 10-03 : COI Configuration
 - 10-03 : PRI Configuration
 - 10-03 : VOIPDB Configuration
 - 10-03 : PRI (T1) Configuration
 - 10-03 : ESI (Channel 1) Configuration
 - 10-04 : Music On Hold Setup
 - 10-08 : Pre-ringing Setup

System Data

10-12 : CPU Network Setup

01 - IP Address	<input type="text" value="0.0.0.0"/>
02 - Subnet Mask	<input type="text" value="255.255.255.0"/>
03 - Default Gateway	<input type="text" value="192.168.1.1"/>
04 - Time Zone	<input type="text" value="(GMT -05:00) Eastern Time (US and Canada)"/>
05 - NIC Setting	<input type="text" value="Automatic detection"/>
07 - NAPT Router IP Address	<input type="text" value=""/>
08 - ICMP Redirect	<input type="checkbox"/>
09 - VOIPDB IP Address	<input type="text" value="192.168.1.90"/>
10 - VOIPDB Subnet Mask	<input type="text" value="255.255.255.0"/>
11 - VOIPDB NIC Setting	<input type="text" value="Automatic detection"/>

Use Program 10-12: CPU Network Setup to setup the IP Address, Subnet-Mask and Default Gateway addresses.

Search

Memory Blocks (Group By Id)

- 10-XX: System Configuration
 - 10-01 : Time and Date Setup
 - 10-02 : Location Setup
 - 10-03 : ESI (Channel 1) Configuration
 - 10-03 : SLI Configuration
 - 10-03 : COI Configuration
 - 10-03 : PRI Configuration

Search

Memory Blocks (Group By Id)

- 10-XX: System Configuration
 - 10-01 : Time and Date Setup
 - 10-02 : Location Setup
 - 10-03 : ESI (Channel 1) Configuration
 - 10-03 : SLI Configuration
 - 10-03 : COI Configuration
 - 10-03 : PRI Configuration
 - 10-03 : VOIPDB Configuration
 - 10-03 : PRI (T1) Configuration
 - 10-03 : ESI (Channel 1) Configuration
 - 10-04 : Music On Hold Setup
 - 10-08 : Pre-ringing Setup
 - 10-09 : DTMF and Dial Tone Circuit Setup
 - 10-12 : CPU Network Setup
 - 10-13 : DHCP Server Setup
 - 10-14 : Managed Network Setup
 - 10-15 : Client Information Setup
 - 10-16 : Option Information Setup
 - 10-19 : VOIPDB DSP Resource Selection
 - 10-20 : External Equipment LAN Setup
 - 10-23 : IP System Interconnection Setup
 - 10-24 : Daylight Savings Setup
 - 10-26 : IP System Operation Setup
 - 10-27 : Networking System Interconnection
 - 10-28 : SIP System Information Setup
 - 10-29 : SIP Server Information Setup
 - 10-31 : Networking KeepAlive Setup
 - 10-33 : SIP Registrar/Proxy Information Setup
 - 10-36 : SIP Trunk Registration Information
 - 10-37 : UPnP Setup

System Data

10-28 : SIP System Information Setup

- 01 - Domain Name
- 02 - Host Name
- 03 - Transport Protocol
- 05 - Domain Assignment
- 06 - IP Trunk Port Binding ☐

This program sets basic system information used in SIP Trunk

System Data

10-29 : SIP Server Information Setup

- 01 - Outbound Default Proxy ☒
- 02 - Inbound Default Proxy ☐
- 03 - Default Proxy IP Address
- 04 - Default Proxy Port
- 05 - Register Mode
- 06 - Registrar IP Address
- 07 - Registrar Port
- 08 - DNS Mode ☒
- 09 - DNS IP Address
- 10 - DNS Port
- 11 - Registrar Domain Name
- 12 - Proxy Domain Name
- 13 - Proxy Host Name
- 14 - SIP Carrier Choice
- 15 - Registration Expiry Time
- 16 - Register Sub Mode ☐
- 17 - DNS Source Port
- 20 - Authentication Trial
- 21 - NAT Router

This program sets the information of SIP Server this system uses

Search Go

Memory Blocks (Group By Id)

- 10-XX: System Configuration
 - 10-01 : Time and Date Setup
 - 10-02 : Location Setup
 - 10-03 : ESI (Channel 1) Configuration
 - 10-03 : SLI Configuration
 - 10-03 : COI Configuration

System Data

10-33 : SIP Registrar/Proxy Information Setup

- 01 - Registration Expiry Time
- 02 - Authentication Mode ☒
- 03 - Registrar/Proxy Domain Name
- 04 - Registrar/Proxy Host Name
- 05 - NAT Mode ☒

This program sets the basic information of SIP Registrar/Proxy

System Data

10-36 : SIP Trunk Registration Information

		voip.ms account user		password
Registration ID	Registration	User ID	Authentication User ID	Authentication Password
00	<input checked="" type="checkbox"/>	<input type="text" value="158466"/>	<input type="text" value="158466"/>	<input type="text" value="....."/>
01	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
02	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
03	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
04	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
05	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
06	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
07	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Enter any characters

Search Go

System Data

10-40 : IP Trunk Availability

- 01 - IP Trunk Availability ☒
- 02 - IP Trunk Port Count

This program sets the availability of SIP Trunks. A reset of the VOIPDB is required for changes to take effect.

- 10-23 : IP System Interconnection Setup
- 10-24 : Daylight Savings Setup
- 10-26 : IP System Operation Setup
- 10-27 : Networking System Interconnector

Search

Memory Blocks (Group By Id)

- ☒ 10-XX: System Configuration
- ☒ 11-XX: System Numbering Plan
- ☒ 12-XX: Night Mode Service
- ☒ 13-XX: Speed Dialing
- ☒ 14-XX: Trunk Setup
 - 14-01 : Trunk Basic Setup
 - 14-02 : Analog Trunk Setup
 - 14-04 : Behind PBX Setup
 - 14-05 : Trunk Groups
 - 14-06 : Trunk Group Routing
 - 14-07 : Trunk Access Map Setup
 - 14-08 : Music On Hold Source for Trunks
 - 14-09 : Conversation Recording Destination
 - 14-11 : IP Trunk ID Setup
 - 14-12 : SIP Register ID Setup for IP Trunks
 - 14-18 : IP Trunk Data Setup
- ☒ 15-XX: Extension Setup
- ☒ 16-XX: Department Groups
- ☒ 20-XX: System Options
 - 20-01 : System Options
 - 20-02 : Multi-Line Telephone System Option
 - 20-03 : Single Line Telephone System Option
 - 20-04 : Virtual Extension System Options
 - 20-06 : Class of Service for Extensions
 - 20-07 : Class of Service Options (Administrative)
 - 20-08 : Class of Service Options (Outgoing)
 - 20-09 : Class of Service Options (Incoming)
 - 20-10 : Class of Service Options (Answer Speed)
 - 20-11 : Class of Service Options (Hold/Transfer)
 - 20-12 : Class of Service Options (Charging)
 - 20-13 : Class of Service Options (Supplementary)
 - 20-14 : Class of Service Options (DISA/E&M)
 - 20-15 : Ring Pattern Cycle Setup
 - 20-16 : Selectable Display Messages
 - 20-17 : Operator's Extension
 - 20-18 : Service Tone Timer
 - 20-19 : Caller ID System Options
 - 20-20 : Message Setup for Non-Caller ID Display
 - 20-21 : Long Conversation System Options
 - 20-23 : CTI System Options
 - 20-25 : ISDN System Options
 - 20-26 : Charge Cost Multiplier
 - 20-28 : Trunk to Trunk Conversation System
 - 20-29 : Timer Class for Extensions
 - 20-30 : Timer Class for Trunks
 - 20-31 : Timer Class Timer Settings
 - 20-34 : Conference Group Setup
 - 20-35 : Extension Operator Setting

System Data

14-01 : Trunk Basic Setup

- | | |
|---------------------------------------------------------|-----------------------------------------------|
| 01 - Trunk Name | <input type="text" value="Line 001"/> |
| 02 - Transmit Gain Level | <input type="text" value="32"/> |
| 03 - Receive Gain Level | <input type="text" value="32"/> |
| 04 - Conference and Transfer Calls Transmit Gain Level | <input type="text" value="32"/> |
| 05 - Conference and Transfer Calls Receive Gain Level | <input type="text" value="16"/> |
| 06 - SMDR Print-out | <input checked="" type="checkbox"/> |
| 07 - Outgoing Calls | <input checked="" type="checkbox"/> |
| 08 - Toll Restriction | <input checked="" type="checkbox"/> |
| 09 - Private Line | <input type="text" value="Normal"/> |
| 10 - Outgoing Call DTMF Tone | <input type="checkbox"/> |
| 11 - Account Code Requirement | <input checked="" type="checkbox"/> |
| 13 - Trunk to Trunk Transfer | <input checked="" type="checkbox"/> |
| 14 - Long Conversation Cut-off | <input type="checkbox"/> |
| 15 - Long Conversation Alarm before Cut-off | <input type="checkbox"/> |
| 16 - Long-time Holding Forced Release | <input type="checkbox"/> |
| 17 - Trunk to Trunk Long Conversation Warning Tone | <input type="checkbox"/> |
| 18 - Warning Beep Tone Signaling | <input type="checkbox"/> |
| 19 - Privacy Mode Toggle Option | <input type="checkbox"/> |
| 20 - Block Outgoing Caller ID | <input type="checkbox"/> |
| 21 - Caller ID Block Code | <input type="text" value="*67"/> |
| 22 - Caller ID to Voice Mail | <input checked="" type="checkbox"/> |
| 24 - Trunk to Trunk Outgoing Caller ID Through Mode | <input checked="" type="checkbox"/> |
| 25 - Continued/Discontinued Trunk to Trunk Conversation | <input type="checkbox"/> |
| 26 - Automatic Trunk to Trunk Transfer Mode | <input type="text" value="Normal transfer"/> |
| 27 - Caller ID Refuse | <input type="checkbox"/> |
| 28 - Conversation Recording Destination for Extension | <input checked="" type="checkbox"/> |
| 30 - Flexible Ringing by Caller ID | <input checked="" type="checkbox"/> |
| 32 - Anti-trombone Function | <input type="checkbox"/> |
| 33 - APSU Trunk Receive Gain | <input type="text" value="32"/> |
| 36 - Calling Party Name Notification | <input type="checkbox"/> |
| 38 - Outgoing CLI selection | <input type="text" value="Contract Number"/> |
| 39 - CLI composition | <input type="text" value="Prefer extension"/> |
| 40 - ISDN Queue announcement connect mode | <input type="text" value="send CONNECT"/> |
| 41 - Incoming Caller Name Usage | <input type="text" value="Use"/> |
| 46 - Collect Call Blocking | <input type="text" value="Disable"/> |

Search

Memory Blocks (Group By Id)

- ☒ 10-XX: System Configuration
- ☒ 11-XX: System Numbering Plan
- ☒ 12-XX: Night Mode Service
- ☒ 13-XX: Speed Dialing
- ☒ 14-XX: Trunk Setup
 - 14-01 : Trunk Basic Setup
 - 14-02 : Analog Trunk Setup**
 - 14-04 : Behind PBX Setup
 - 14-05 : Trunk Groups
 - 14-06 : Trunk Group Routing
 - 14-07 : Trunk Access Map Setup
 - 14-08 : Music On Hold Source for Trunks
 - 14-09 : Conversation Recording Destination
 - 14-11 : IP Trunk ID Setup
 - 14-12 : SIP Register ID Setup for IP Trunks
 - 14-18 : IP Trunk Data Setup
- ☒ 15-XX: Extension Setup
- ☒ 16-XX: Department Groups
- ☒ 20-XX: System Options
 - 20-01 : System Options
 - 20-02 : Multi-Line Telephone System Option
 - 20-03 : Single Line Telephone System Option
 - 20-04 : Virtual Extension System Options
 - 20-06 : Class of Service for Extensions
 - 20-07 : Class of Service Options (Administrative)
 - 20-08 : Class of Service Options (Outgoing)
 - 20-09 : Class of Service Options (Incoming)

System Data

14-02 : Analog Trunk Setup

- 01 - Signaling Type
- 02 - Incoming Call Detection Type
- 03 - Flash Type
- 04 - Hooking Type
- 05 - Dial Tone Detection for Directly Accessed Trunks ☐
- 06 - Pause at 1st-digit after Line Seizure in Manual Dial Mode ☒
- 07 - DP to DTMF Conversion
- 08 - Answering Condition
- 09 - Busy Tone Detection ☐
- 10 - Caller ID ☒
- 11 - Next Trunk in Rotary if No Dial Tone ☐
- 12 - Detect Network Disconnect Signal ☒
- 13 - Trunk to Trunk Limitation ☐
- 18 - Busy Tone Detection on Talking ☐
- 19 - Busy Tone Detection Frequency
- 20 - Busy Tone Detection Interval
- 23 - Caller ID Receiving Method
- 24 - Use Call Waiting Caller ID ☒

Use Program 14-02: Analog Trunk Data Setup to set the basic options for each analog trunk port. R

System Data

14-05 : Trunk Groups

Trunk Trunk Group Priority

1	<input type="text" value="1"/>	<input type="text" value="5"/>
2	<input type="text" value="1"/>	<input type="text" value="6"/>
3	<input type="text" value="1"/>	<input type="text" value="7"/>
4	<input type="text" value="1"/>	<input type="text" value="8"/>
5	<input type="text" value="2"/>	<input type="text" value="1"/>
6	<input type="text" value="2"/>	<input type="text" value="2"/>
7	<input type="text" value="2"/>	<input type="text" value="3"/>
8	<input type="text" value="2"/>	<input type="text" value="4"/>

- 10-47 : Terminal License Server Information
- 10-51 : PRI (PRI/T1) Mode Selection
- 10-52 : Demo License Information
- 10-54 : Blade License Setup
- 10-58 : Intranet Local Network Area Setup
- 10-60 : Audio Port Setup
- 10-61 : Relay Port Setup
- 10-62 : NetBIOS Setting
- 10-63 : DHCP Client Setting
- 10-65 : NTP Server Setting

- ☒ 11-XX: System Numbering Plan
- ☒ 12-XX: Night Mode Service

Search Go

System Data

14-06 : Trunk Group Routing

10-4/ : Terminal License Server Information
10-51 : PRI (PRI/T1) Mode Selection
10-52 : Demo License Information
10-54 : Blade License Setup
10-58 : Intranet Local Network Area Setup
10-60 : Audio Port Setup
10-61 : Relay Port Setup
10-62 : NetBIOS Setting
10-63 : DHCP Client Setting
10-65 : NTP Server Setting

11-XX: System Numbering Plan

12-XX: Night Mode Service

13-XX: Speed Dialing

14-XX: Trunk Setup

14-01 : Trunk Basic Setup

14-02 : Analog Trunk Setup

Route Table	Priority Order			
	1	2	3	4
01	<input type="text" value="2"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
02	<input type="text" value="2"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
03	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
04	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
05	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
06	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
07	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
08	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
09	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
10	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>

Search Go

System Data

14-07 : Trunk Access Map Setup

10-4/ : Terminal License Server Information
10-51 : PRI (PRI/T1) Mode Selection
10-52 : Demo License Information
10-54 : Blade License Setup
10-58 : Intranet Local Network Area Setup
10-60 : Audio Port Setup
10-61 : Relay Port Setup
10-62 : NetBIOS Setting
10-63 : DHCP Client Setting
10-65 : NTP Server Setting

11-XX: System Numbering Plan

12-XX: Night Mode Service

13-XX: Speed Dialing

Trunk

-
-
-
-
-
-
-
-

Search Go

System Data

14-18 : IP Trunk Data Setup

05 - SIP Profile

Use Program 14-18: IP Trunk Data Setup to set the options for each IP Trunk port.

10-4/ : Terminal License Server Information
10-51 : PRI (PRI/T1) Mode Selection
10-52 : Demo License Information
10-54 : Blade License Setup
10-58 : Intranet Local Network Area Setup

Search

21-XX: Trunk Data Setup

15-XX: Extension Setup

16-XX: Department Groups

20-XX: System Options

21-XX: Outgoing Call Service

21-01: Outgoing Calls System Options

21-02: Trunk Group Routing for Extensions

21-03: Trunk Group Routing for Trunks

21-04: Toll Restriction Class for Extensions

21-05: Toll Restriction Class

21-06-01: Toll Restriction - International C

21-06-02: Toll Restriction - International C

21-06-03: Toll Restriction - Maximum Num

21-06-04: Toll Restriction - Common Permi

21-06-05: Toll Restriction - Common Restr

21-06-06: Toll Restriction - Permit Code T

21-06-07: Toll Restriction - Restrict Code T

21-06-08: Toll Restriction - Trunk Access C

21-06-09: Toll Restriction - Specified Acces

21-06-10: Toll Restriction - Special Service

21-07: Toll Restriction Override Password !

21-08: Redial Setup

21-09: Dial Block Setup

21-10: Dial Block Restriction Class for Exte

21-11: Hotline Assignment

21-12: ISDN Calling Party Number Setup f

21-13: ISDN Calling Party Number Setup f

21-14: Walking Toll Restriction Password S

21-15: Individual Trunk Group Routing for

21-16: Trunk Group Routing for Networks

21-17: IP Trunk (SIP) Calling Party Numbe

21-19: IP Trunk (SIP) Calling Party Numbe

21-20: SIP Trunk Call Disconnection Setup f

Memory Blocks (Group By Id)

10-XX: System Configuration

11-XX: System Numbering Plan

12-XX: Night Mode Service

13-XX: Speed Dialing

14-XX: Trunk Setup

14-01: Trunk Basic Setup

14-02: Analog Trunk Setup

14-04: Behind PBX Setup

14-05: Trunk Groups

14-06: Trunk Group Routing

14-07: Trunk Access Map Setup

14-08: Music On Hold Source for Trunks

14-09: Conversation Recording Destination

14-11: IP Trunk ID Setup

14-12: SIP Register ID Setup for IP Trunks

14-18: IP Trunk Data Setup

System Data

21-01: Outgoing Calls System Options

01 - Seizure Trunk Line Mode

Priority Route ▼

02 - Internal Call Inter-digit Time

10

03 - External Call Inter-digit Time

5

04 - Dial Tone Detection

5

05 - Disconnection Time when Dial Tone not detected

3

06 - Dial Pause at 1st-digit

1

07 - Toll Restriction Override Release

10

08 - Preset Dial Display Hold Time

10

09 - Hotline Call Start Time

5

10 - Dial Digits for Toll Restriction Path Control

0

11 - Inter-digit Time for Toll Restriction Path Control

0

12 - Dial 911 Routing without Trunk Access

Trunk Access Code not required ▼

13 - Alarm Ring Time (E911)

0

14 - Forced Account Code Inter-digit Time

3

15 - Outgoing Disable on Incoming Line

☐

16 - Supervise Dial Detection Time

20

17 - Restriction Digit in Outgoing Disable on Incoming Line

4

18 - Reset Dial after Trunk Access Failure

Disabled ▼

19 - Do-Not-Call Setup

No Service ▼

20 - Caller ID Callback with Home Area Code Mode

Disable ▼

21 - HNP Exception Type

Toll ▼

22 - 10Digit Local Calls

7 Digits ▼

System Data

20-02: Multi-Line Telephone System Options

01 - Trunk Group Key Operation Mode

Extinction ▼

02 - Trunk Group Access Key Operation Mode

Outgoing/Incoming ▼

04 - Retrieve Line After Transfer

Holding ▼

05 - Headset Busy Mode

☐

06 - Pre-selection Time

5

07 - Date/Time Display Mode

MM-DD WWW hh:mm(12h) ▼

08 - Display Holding Time

5

09 - Disconnect Supervision

☒

10 - Time Before Shifting to Power Saving Mode

Power Saving Mode Off ▼

11 - Default Setting of Microphone of Key Telephone

☒

12 - Forced Intercom Ringing

Signal ▼

15 - Caller ID Information Display for DSTU

Name and Number ▼

18 - Dialing Record Display Time

30

19 - DSS Key - Virtual Extension Mode

☐

24 - LCD scroll mode

Character ▼

20-03 : Single Line Telephone System Options
 20-04 : Virtual Extension System Options
 20-06 : Class of Service for Extensions
 20-07 : Class of Service Options (Administrative)
 20-08 : Class of Service Options (Outgoing)
 20-09 : Class of Service Options (Incoming)
 20-10 : Class of Service Options (Answer Speed)
 20-11 : Class of Service Options (Hold/Transfer)
 20-12 : Class of Service Options (Charging)
 20-13 : Class of Service Options (Supplemental)
 20-14 : Class of Service Options (DISA/E&M)
 20-15 : Ring Pattern Cycle Setup
 20-16 : Selectable Display Messages
 20-17 : Operator's Extension
 20-18 : Service Tone Timer
 20-19 : Caller ID System Options
 20-20 : Message Setup for Non-Caller ID Display
 20-21 : Long Conversation System Options
 20-23 : CTI System Options
 20-25 : ISDN System Options
 20-26 : Charge Cost Multiplier
 20-28 : Trunk to Trunk Conversion System
 20-29 : Timer Class for Extensions
 20-30 : Timer Class for Trunks
 20-31 : Timer Class Timer Settings
 20-34 : Conference Group Setup
 20-35 : Extension Operator Setting
 20-36 : Trunk Operator Setting
 20-37 : Operator Extension Group Setup
 20-38 : Operator Group Settings
 20-42 : Day/Night mode for each package
 20-43 : Power supply mode for each package
 20-44 : Watch Mode Setup
 20-45 : Remote Watch Setup
 20-46 : Security Sensor Setup
 20-47 : Time pattern setting for Watch Mode
 20-48 : Time pattern setting for security Sensor
 20-49 : Caller ID Shared Group Basic Data
 20-55 : Delay Timer for Security Sensor
 20-57 : US User Information Settings

System Data

20-08 : Class of Service Options (Outgoing Call Service)

- | | |
|-----------------------------------------------------------------|-------------------------------------|
| 01 - Internal Call | <input checked="" type="checkbox"/> |
| 02 - Outgoing Trunks | <input checked="" type="checkbox"/> |
| 03 - Speed Dials Common | <input checked="" type="checkbox"/> |
| 04 - Speed Dials Group | <input checked="" type="checkbox"/> |
| 05 - Preview Dial Number | <input checked="" type="checkbox"/> |
| 06 - Toll Restriction Override | <input type="checkbox"/> |
| 07 - Redial Repeat | <input checked="" type="checkbox"/> |
| 08 - Toll Restriction Dial Blocking | <input checked="" type="checkbox"/> |
| 09 - Hotline for Handpiece | <input checked="" type="checkbox"/> |
| 10 - Handsfree Answerback/Forced Intercom Ringing Switching | <input checked="" type="checkbox"/> |
| 11 - Call Mode Switching Protection from Caller (Internal Call) | <input type="checkbox"/> |
| 12 - Department Group Step Calling | <input checked="" type="checkbox"/> |
| 13 - ISDN Clip | <input checked="" type="checkbox"/> |
| 14 - Set Calling Sub Address | <input type="checkbox"/> |
| 15 - Block Outgoing Caller ID | <input type="checkbox"/> |
| 16 - E911 Dialed Extension Name and Number Display | <input type="checkbox"/> |
| 17 - ARS Override of Trunk Access Map | <input type="checkbox"/> |
| 19 - Hotline for Speaker | <input type="checkbox"/> |
| 20 - Hot Key Pad | <input type="checkbox"/> |
| 21 - Automatic Trunk Seizing by Pressing SPK Key | <input type="checkbox"/> |
| 22 - Voice Over to Busy Virtual Extension | <input type="checkbox"/> |
| 23 - Display indication for security sensor detection | <input type="checkbox"/> |
| 24 - Display indication for emergency call by remote inspection | <input type="checkbox"/> |

21-06-10 : Toll Restriction - Special Service
 21-07 : Toll Restriction Override Password
 21-08 : Redial Setup
 21-09 : Dial Block Setup
 21-10 : Dial Block Restriction Class for Extensions
 21-11 : Hotline Assignment
 21-12 : ISDN Calling Party Number Setup for Extensions
 21-13 : ISDN Calling Party Number Setup for Trunks
 21-14 : Walking Toll Restriction Password Setup
 21-15 : Individual Trunk Group Routing for Extensions
 21-16 : Trunk Group Routing for Networks
 21-17 : IP Trunk (SIP) Calling Party Number Setup
 21-19 : IP Trunk (SIP) Calling Party Number Setup for Trunks
 21-20 : CTI Trunk Call Disconnection Setup

System Data

21-17 : IP Trunk (SIP) Calling Party Number Setup for Trunks

Trunk Calling Party Number

1	<input type="text"/>
2	<input type="text"/>
3	<input type="text"/>
4	<input type="text"/>
5	<input type="text"/>
6	<input type="text"/>
7	<input type="text"/>
8	<input type="text"/>

DID

Search Go

- 15-18 : Virtual Extension Key Enhanced Op
- 15-20 : LCD Line Key Name Assignment
- 15-22 : Mobile Extension Setup
- 15-24 : Registration setting in the standard
- 15-28 : Trunk Incoming Ring Tone of Exter

- 16-XX: Department Groups
- 20-XX: System Options
- 21-XX: Outgoing Call Service
 - 21-01 : Outgoing Calls System Options
 - 21-02 : Trunk Group Routing for Extensions
 - 21-03 : Trunk Group Routing for Trunks
 - 21-04 : Toll Restriction Class for Extensions
 - 21-05 : Toll Restriction Class
 - 21-06-01 : Toll Restriction - International C

System Data

21-02 : Trunk Group Routing for Extensions

ICM Extension	Night Mode							
	Mode 1	Mode 2	Mode 3	Mode 4	Mode 5	Mode 6	Mode 7	Mode 8
101	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>
102	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>
103	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>
104	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>
105	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>
106	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>
107	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>
108	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>

Use Program 21-02: Trunk Group Routing for Extensions to assign Program 14-06 routes to extensions.

Search Go

- 22-XX: Incoming Call Service
- 23-XX: Answer Service
- 24-XX: Hold/Transfer Service
- 25-XX: VRS/DISA Service

System Data

26-01 : Automatic Route Selection Service

- 01 - ARS Service ☒
- 02 - Network Outgoing Inter-digit ARS Time
- 03 - ARS Incorrect Dialed Number Handling
- 06 - ARS CoS Match Access ☐
- 07 - F-Route Access CoS Reference

Use Program 26-01: Automatic Route Selection Service to define the system options for Aut

Search Go

- 26-11 : Transit Network ID Table
- 26-12 : Network Specified Parameter Table

- 30-XX: DSS/DLS Consoles
- 31-XX: External Speakers and Paging
- 32-XX: Doorphones and Sensors
- 34-XX: Tie Line Setup
- 35-XX: SMDR and Account Codes
- 40-XX: Voice Recording System
- 41-XX: Automatic Call Distribution
- 42-XX: Hotel/Motel Setup
- 44-XX: F-Route
 - 44-01 : F-Route System Options

System Data

44-05 : F-Route Table

	Priority Number			
	1	2	3	4
01 - Trunk Group	<input type="text" value="2"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
02 - Delete Dial Digits	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
03 - Additional Dial Digits Table	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
04 - Beep Tone	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
05 - Gain Table when Internal Call	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
06 - Gain Table when Tandem Connection	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
07 - ARS Class of Service	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
08 - Dial Treatment	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
09 - Maximum Dialing Digit	<input type="text" value="11"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
11 - Network Specified Parameter Table	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>

NEC

Exit

Help

SIP1

SIP2

SIP3

SIP4

ABC

DEF

Flash

Transfer

1

2

3

GHI

JKL

MNO

Mute

DND

4

5

6

PQRS

TUV

WXYZ

Clear/Back

7

8

9

*

0

#

Speaker

Hold

